

Suspension Parts & Poly Bushings for PORSCHE 924 1969-1989 - 922, 924

Parts Application Diagrams

Macpherson Strut

With Separate Control Arm



Generic Diagram

For Illustrative Purposes Only



Available SuperPro Parts

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Camber Adjusting Bolt Kit Adds +/- 1.5 Degrees camber	SPF4351-12K	1	SuperPro SPF
Front	Control Arm Inner-Front Bush Kit	SPF0647K	1	SuperPro SPF
Front	Control Arm Inner-Rear Bush Kit	SPF0648K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-20K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-21.5K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-22K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-23K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-24.5K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-24K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-25.4K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-26K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-27K	1	SuperPro SPF
Front	Sway Bar End Bush Kit Measure end of bar diameter, 20,21.5,22,23,24,24.5,25.4,26,27 & 30mm ava	SPF1169-30K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-20K	1	SuperPro SPF

Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-21.5K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-22K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-23K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-24.5K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-24K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-25.4K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-26K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-27K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit 1986 - 1988. Suits bracket 944 343 731 00	SPF2923-30K	1	SuperPro SPF