


Suspension Parts & Poly Bushings for VOLVO S60 2000-2010 - MK I

Parts Application Diagrams

Generic Diagram

For Illustrative Purposes Only



Generic Diagram

For Illustrative Purposes Only



Available SuperPro Parts

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Bump Stop Kit	SPF1833BK	1	SuperPro SPF
Front	Control Arm Lower-Inner Front Bush Kit Replaces original part number 9443882.	SPF2913K	1	SuperPro SPF
Front	Control Arm Lower-Inner Rear Bush Kit	SPF2910K	1	SuperPro SPF
Front	Engine Steady Mount Bush Kit	SPF2563K	1	SuperPro SPF
Front	Engine Steady Mount Bush Kit Front	SPF4489K	1	SuperPro SPF
Front	Engine Steady Mount Bush Kit Rear	SPF4490K	1	SuperPro SPF
Front	Sway Bar Link Standard Replacement	TRC4049	2	Roll Control
Front	Sway Bar Link Kit - Heavy Duty Adjustable	TRC12265	1	Roll Control
Rear	Sway Bar Link Cut To Length Link	TRC4007	2	Roll Control
Rear	Sway Bar Link Standard Replacement	TRC4046	2	Roll Control
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC1245A	1	Roll Control