


# Suspension Parts & Poly Bushings for BMW 5 2003-2010 - E60, E61

## Parts Application Diagrams


### Macpherson Strut

With Lower Control Arm And Caster Arm



### Complex Multi Link With Active Control

With Upper And Lower Control Arms, Trailing And Toe Control Arms



## Available SuperPro Parts

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Sway Bar Link Kit - Heavy Duty Adjustable	<a href="#">TRC10200</a>	1	Roll Control
Front	Sway Bar Mount Bush Kit Suits Cast Aluminium Bracket, Bracket not included in kit.	<a href="#">SPF2818-24.6K</a>	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit Suits Cast Aluminium Bracket, Bracket not included in kit.	<a href="#">SPF2818-25.5K</a>	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	<a href="#">SPF2570-14K</a>	1	SuperPro SPF